

JIMMYJANE

# REFLEXX RABBIT 2

JJ10304

INSTRUCTIONAL MANUAL





# INCLUDES

- (1) REFLEXX RABBIT 2
- (1) MAGNETIC USB CHARGING CABLE
- (1) STORAGE BAG

## PRODUCT FEATURES & BENEFITS

CLEVERLY DESIGNED WITH A FINGER HOLDER TO SLIP EFFORTLESSLY BETWEEN YOUR FINGERS, THE REFLEXX™ RABBIT 2 HAS TWO INDEPENDENTLY CONTROLLED MOTORS, WARMING TECHNOLOGY, AND A REVOLUTIONARY REFLEXX™ BOUNCE-BACK ACTION. WHEN PRESSURE IS APPLIED, THE REFLEXX™ RABBIT 2 SPRINGS BACK — CREATING A NATURAL ORGASMIC MOTION. EXPLORE DOZENS OF POTENTIAL PLEASURE FREQUENCY COMBINATIONS WHILE YOU SELECT INDEPENDENT VIBRATIONS AND SPEEDS FOR EACH MOTOR AT EACH END. WITH ITS ERGONOMIC FINGER HOLDER AND FULLY WATERPROOF DESIGN, YOU'LL LOVE ITS NATURAL HEATING ELEMENT THAT WARMS UP TO BODY TEMPERATURE.

- Dual independently controlled motors allow you to personalize your pleasure
- The hooked design stimulates the g-spot and clitoris simultaneously
- Comfortable finger holder for an easy no-slip grip
- Each vibrating motor features ten high-performing vibration modes for your every mood
- Warming mode brings the vibrator just above body temperature in a few minutes
- Features a discretionary travel-lock
- Used by women and couples
- Great for clitoral and g-spot stimulation
- Waterproof and washable safe
- Rechargeable, magnetic usb cord and cloth storage bag included



# INSTRUCTIONS

## 1 G-SPOT VIBRATION

Press and hold the top vibration button (closest to the finger holder) for three seconds to turn on the G-spot motor. The LED will light up and the vibrator will start. Each press will cycle through the three speeds & seven modes of vibration and the LED will change in sync with each mode. Press and hold the button for three seconds to turn off.

## 2 WARMING MODE

Press and hold the middle button for three seconds to activate warming mode, the LED will light up and stay solid. The vibrator will now warm to just above body temperature in a few minutes. Press and hold the button for three seconds to turn off.

## 3 CLITORAL VIBRATION

Press and hold the bottom vibration button (closest to plate) for three seconds to turn on the clitoral motor. The LED will light up and the vibrator will start. Each press will cycle through the three speeds & seven modes of vibration and the LED will change in sync with each mode. Press and hold the button for three seconds to turn off.


### TRAVEL LOCK INSTRUCTIONS

**To Lock** - Press and hold the warming button and top button (closest to handle) together for three seconds. The LED will blink and the motor will vibrate once when locked. All functions will turn off when the vibrator is locked.

**To Unlock** - Press and hold the warming button and top button (closest to handle) together for three seconds. The LED will blink and the motor will vibrate twice when unlocked.

### FUNCTIONS / WARMING MODE

EACH MOTOR FEATURES 10 FUNCTION VIBRATIONS (3 SPEEDS + 7 MODES)  
SINGLE WARMING MODE UP TO SLIGHTLY ABOVE BODY TEMPERATURE



# PRODUCT SPECS

USB CHARGING  
LITHIUM BATTERY  
WATERPROOF  
SILICONE

## SIZE

Length: 6.7 in. (17 cm)  
Width: 1.7 in. (4.4 cm)  
Insertable Length: 5 in. (12.8 cm)  
Insertable Diameter: 1.3 in. (3.4 cm)

## CHARGING

3 hours

## RUN TIME

45 minutes

## IPX RATING

IPX7 - FULLY WATERPROOF

Protected against the effects of temporary water submersion at a depth of one meter, for 30 minutes.





# CHARGING INSTRUCTIONS

## CONNECTING MAGNETIC CHARGER

Connect the JimmyJane Magnetic USB Charging Cord to the magnetic charging points on the vibrator. All three LEDs will blink while the vibrator is charging, and will stay solid once fully charged.

This product is only compatible with the JimmyJane Magnetic USB Charging Cord.

- Always ensure both points connect and do not touch any other metal items.
- Do not attempt to charge during use.
- Do not charge near water.



# CARE INSTRUCTIONS

Spray an antibacterial cleaner like the JimmyJane Antibacterial Toy Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.



# WARNING

THIS VIBRATOR IS FOR NOVELTY PURPOSES ONLY, IS NOT INTENDED FOR THERAPEUTIC PURPOSES AND IS RECOMMENDED FOR EXTERNAL USE ONLY. PROLONGED USE FOR MORE THAN 30 MINUTES OR FREQUENT USE OF MORE THAN TWICE DAILY IS NOT ADVISED OR RECOMMENDED. THIS VIBRATOR IS INTENDED FOR ADULT USE ONLY. USE WATER-BASED LUBRICANTS ONLY.

THIS APPLIANCE IS NOT INTENDED FOR USE BY CHILDREN OR PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES. TO AVOID ELECTRIC SHOCK, DO NOT USE CHARGER NEAR WATER. DO NOT USE ON SWOLLEN OR INFLAMED AREAS OF SKIN. DISCONTINUE USE IF DISCOMFORT OCCURS. DO NOT USE ON NECK OR SPINE AREAS.

- Do not use with silicone lubricants because they may damage the product.
- Do not clean with products that contain alcohol, petrol, or acetone.
- Do not boil, bake, microwave, or put this product in a dishwasher since it may damage the electronic components and present a serious FIRE HAZARD.
- Do not store in extreme temperatures.
- Do not charge near water.

# MAGNETIC CHARGER WARNING

- WARNING - Do not allow the magnetic charge cord to attach to any magnetic / metallic surface while it is plugged in.
- Only use this cord with JimmyJane products.
- Before charging, make sure charger is free from water or lubricant residue.
- Do not charge near water.
- Product will not charge if it is too hot (115 degrees Fahrenheit/+46 degrees Celsius). Once the temperature of product reaches a safe level, charging will begin automatically.

# LITHIUM BATTERY WARNING


- Rechargeable Lithium Ion batteries are potentially hazardous and can present a serious FIRE HAZARD if damaged, defective, or improperly used.

# JIMMYJANE PAIRINGS

- Magnetic USB Charging Cord
- Intimate Lubricant
- Sensation Lubricant
- Toy Lubricant
- Antibacterial Toy Cleaner

## DISPOSAL OF OLD ELECTRONIC EQUIPMENT

THE CROSSED-OUT DUSTBIN (WEEE) SYMBOL INDICATES THAT THIS PLEASURE OBJECT SHOULD NOT BE TREATED AS HOUSEHOLD WASTE, BUT RATHER BE BROUGHT TO THE APPROPRIATE COLLECTION POINT FOR RECYCLING OF ELECTRICAL AND ELECTRONIC EQUIPMENT.



PATENTS: [WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES](http://WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES)

WARRANTY: [WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY](http://WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY)



JIMMYJANE